# DUZcart limited one year warranty

DUZcart warrants it product for a period of one year from the date of original purchase. We will repair or replace at our option, any part or parts of the product and accessories covered under this warranty which, after examination, proves to be defective in workmanship or material during the warranty period. For repair or replacement, contact us at 888-389-2278. Repairs/replacement will be made transportation prepaid. Proof of purchase may be required. This warranty does not apply to misuse, abuse, normal wear and tear or repairs attempted or made by other than our Service Center.

ANY IMPLIED WARRANTY, INCLUDING THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE, WILL LAST ONLY FOR ONE (1) YEAR FROM THE DATE OF PURCHASE.

# CAUTION

- Insure the ladder is fully extended and level when placed inside the DUZcart
- Follow general ladder safety rules and regulations
- Before entering the DUZcart, insure the wheels are locked and the DUZcart is placed on a flat, level surface.
- Keep the DUZcart clean. The floor can be easily cleaned with glass cleaner and a soft cloth
- Be aware of your surroundings in case the DUZcart needs to be moved.

474 Park 800 Drive, Greenwood, Indiana 46143 1-888-389-2278





**OWNER'S MANUAL** 

## Call 1-888-389-2278 for additional assistance.

The DUZcart is shipped fully assembled and ready for use. There are no further adjustments to be made to the DUZcart.

The DUZcart is assembled with 2 stationary casters and 2 locking-swivel casters. Keep the casters locked when the DUZcart is not in transport mode. Always lock the casters prior to entering the cart.

The DUZcart will accommodate a fully extended 6' or 8' folding ladder. Please follow proper ladder safety rules.

The outside hose attachment will accommodate a standard HEPA vacuum hose to create negative air pressure inside the DUZcart. An Optional 8" scrubber attachment is also available.

Directions for use:

1. Position the DUZcart on a flat, level area prior to beginning work.

#### 2. Lock the casters!

- **3.** Attach vacuum hose to the DUZcart hose attachment (figure 1). Plug in and power on the HEPA vac.
- 4. Some facilities require outside personnel to monitor the area in which the cart is being used. This person is t monitor the area outside of the DUZcart and notify the person working inside the DUZcart of possible hazards.
- 5. Enter the DUZcart, zip the flap-door closed.
- 6. Fully extend a 6' or 8' ladder and confirm the ladder is level.
- 7. Place both DUZcart locking mechanisms into the "Lock" position (figure 2).
- 8. Lift center poles until the top frame rests securely against the ceiling. Raise the cart to create a tight seal, but do not lift the ceiling.
- 9. Remove the ceiling tiles or ceiling access to perform required work.
- **10.** After the above ceiling work is completed, close the ceiling or ceiling access. Unlock the DUZcart lock mechanisms (figure 3) and lower the DUZcart.
- 11. Collapse the extended ladder, if necessary.
- 12. Unzip the DUZcart door-flap.
- 13. Remove the HEPA vac hose attachment from the DUZcart, if necessary.
- 14. Power off and unplug the HEPA vac.
- 15. Unlock the DUZcart casters and advance to the next work area.
- 16. Clean the DUZcart thoroughly after each use.



### For a complete demonstration video on the use of the DUZcart Dust Containment cart, visit our website: www.DUZcart.com.



Figure 1. DUZcart HEPA vac hose attachment.



Figure 2. DUZcart locking mechanism (Locked position)




Figure 3. DUZcart locking mechanism (Unlocked position)